



ISRI NTS 6860/870 self level air seat - Operator instructions

SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED

Air Lumbar Support - Two lumbar chambers, Lower (LL) & upper (UL) plus air adjustable side bolsters (SB). Press the + to increase and - to decrease. Adjust to give the lumbar region of your back the desired support.

THREE POINT SEATBELT

Backrest Adjustment

First apply **light** pressure to backrest, then gently lift lever up and lean rearward against backrest or lean forward to adjust the backrest incline.

Seat Height Adjust

Gently pull the lever up to raise seat height, gently push down to lower seat height.

Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit road conditions.

Air Dump Valve

Gently press button in at the top once seated, before exiting press button down. This improves entry & exit clearance.

Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock



Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push Hips forward/backwards. Release to lock.

Horizontal Isolator (where fitted)

Push the lever to the right for isolator function to operate, push the lever to the left to lock the isolator.

Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.

For further information contact ISRI Seats Ph. 02 9756 6199

www.isri.com.au