

# ISRI 6800/337 Air Suspension Drivers Seat Operator Instructions



**Backrest Adjustment**  
**First** apply **very light** pressure to backrest, then Gently pull the lever up and lean rearward on the backrest or lean forward to adjust the backrest incline. Release lever to lock.

**Air Dump Valve**  
 Gently pull lever up to dump air from seat. This is useful in getting in and out of the seat. When you get into the seat, push the lever down, the seat suspension will automatically adjust to the operator weight.

**Seat Cushion Adjustment**  
 The seat cushion can be adjusted in length so to provide more support under your legs. Gently pull the lever up whilst sitting on the seat and push hips forward/backwards.

**Seat Forward/Back Adjust**  
 Gently pull the bar up and slide seat back/forward to adjust for the length of your legs and comfort

**Seat Isolator adjustment: IF FITTED**  
 The horizontal seat isolator (button on the right) locks the seat from rocking back and forth. Push the lever to the left to lock the seat, push it to the right to unlock the seat.

**Lap Sash Seat Belt**  
 Optimum safety.

**Air Lumbar Support**  
 The seat has 3 lumbar supports – upper, lower and two on the side. Press the + to increase and – to decrease. Adjust to give the lumbar region of your back the desired support.

**Seat Damper Adjust**  
 Gently push the lever down for a softer suspension, and pull the lever up for a firmer suspension. Damper can be set in various positions to suit the ride conditions. For optimum seat performance, adjust damper to suit road conditions.

**Seat Height Adjust**  
 Gently pull the lever up to raise seat height, gently push down to lower seat height.

**Seat Tilt Adjust**  
 Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down.