



ISRI NCS 6830KA/877 Air Suspension Seat - Operator instructions

SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED

Seat Harness

Put harness on and adjust waist straps on each side of the seat so that the lap section of the harness crosses your waist.

Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.

Height Adjustment

Sit on the seat and turn the knob to the lowest position. Once the seat has lifted you and stopped turn the knob so that seat is adjusted to the required height.

Before you get out of the seat turn the knob to the lowest position.

The seat is suitable for an operator weight of 50 to 150kg.



Backrest Adjustment

Apply light pressure to backrest and gently lift lever and lean rearward/forward to adjust the backrest incline. Release lever to lock.

IPS Air Lumbar Support

Press the (+) to increase and (-) to decrease. Adjust individual chambers to give the Lumbar region of your back the desired Support.

Note- When operating lumbar seat will exhaust then return to seated height.

Horizontal Isolator

Pull the lever up for isolator function to operate. Push the lever down to lock the Isolator into a locked position.

Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit conditions.

For further information contact

ISRI Seats

Phone: (02) 9756 6199

Web: www.isri.com.au



ISRI NCS 6830KA/877 Air Suspension Seat - Operator instructions

SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED

Seat Harness

Put harness on and adjust waist straps on each side of the seat so that the lap section of the harness crosses your waist.

Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.

Height Adjustment

Sit on the seat and turn the knob to the lowest position. Once the seat has lifted you and stopped turn the knob so that seat is adjusted to the required height.

Before you get out of the seat turn the knob to the lowest position.

The seat is suitable for an operator weight of 50 to 150kg.



Backrest Adjustment

Apply light pressure to backrest and gently lift lever and lean rearward/forward to adjust the backrest incline. Release lever to lock.

IPS Air Lumbar Support

Press the (+) to increase and (-) to decrease. Adjust individual chambers to give the Lumbar region of your back the desired Support.

Note- When operating lumbar seat will exhaust then return to seated height.

Horizontal Isolator

Pull the lever up for isolator function to operate. Push the lever down to lock the Isolator into a locked position.

Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit conditions.

For further information contact
ISRI Seats

Phone: (02) 9756 6199

Web: www.isri.com.au



ISRI NCS 6830KA/877 Air Suspension Seat - Operator instructions

SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED

Seat Harness

Put harness on and adjust waist straps on each side of the seat so that the lap section of the harness crosses your waist.

Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.

Height Adjustment

Sit on the seat and turn the knob to the lowest position. Once the seat has lifted you and stopped turn the knob so that seat is adjusted to the required height.

Before you get out of the seat turn the knob to the lowest position.

The seat is suitable for an operator weight of 50 to 150kg.



Backrest Adjustment

Apply light pressure to backrest and gently lift lever and lean rearward/forward to adjust the backrest incline. Release lever to lock.

IPS Air Lumbar Support

Press the (+) to increase and (-) to decrease. Adjust individual chambers to give the Lumbar region of your back the desired Support.

Note- When operating lumbar seat will exhaust then return to seated height.

Horizontal Isolator

Pull the lever up for isolator function to operate. Push the lever down to lock the Isolator into a locked position.

Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit conditions.

For further information contact
ISRI Seats

Phone: (02) 9756 6199

Web: www.isri.com.au