



ISRI NCS 6830KM/880 Air Suspension Seat - Operator instructions

SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED

Backrest Adjustment

First apply **light** pressure to backrest, then gently lift lever up and lean rearward against backrest or lean forward to adjust the backrest incline. Release lever to lock.

IPS Air Lumbar Support

Press the + to increase and - to decrease. Adjust individual chambers to give the lumbar region of your back the desired Support.

Note: You may need to adjust Air Suspension Adjustment after inflating IPS.



Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.



Retractable Lap Seat Belt

Air Suspension Adjustment

Press the + / - button to adjust the seat into the desired position.

In addition, adjust the shock absorber (as mentioned) to the road conditions to achieve the most comfortable seating position.



Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.

Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit road conditions.

For further information contact ISRI Seats Ph:- (02) 9756 6199

www.isri.com.au