



## ISRI NCS 6830KM/880 Air Suspension Seat - Operator instructions

**SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED**

### **Seat Cushion Adjustment**

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

### **Seat Tilt Adjust**

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

### **Slide Adjust**

Lift slide handle and slide seat back/forward to the required position. Release to lock.



### **Air Suspension Adjustment**

Press the + / - button to adjust the seat into the desired position.

In addition, adjust the shock absorber (as mentioned) to the road conditions to achieve the most comfortable seating position.



### **Backrest Adjustment**

**First** apply **light** pressure to backrest, then gently lift lever up and lean rearward against backrest or lean forward to adjust the backrest incline. Release lever to lock.

**Air Lumbar Support** – Two lumbar chambers, lower (LL) & upper (UL). Press the upper area of the knobs to increase and the lower area to decrease. Adjust to give the lumbar region of your choice the desired support.



### **Shock Absorber Adjustment**

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit road conditions.