



ISRI NCS 6830KM/880 Air Suspension Seat - Operator instructions

SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED

Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock

Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.

Air Suspension Adjustment

Press the + to increase and - to decrease the air pressure in the seat suspension. The optimum setting being middle of the suspension stroke. ***This is not to be used as height control***

Backrest Adjustment

First apply **light** pressure to backrest, then gently lift lever up and lean rearward against backrest or lean forward to adjust the backrest incline. Release lever to lock.

Air Lumbar Support - Two lumbar chambers, Lower (LL) & upper (UL). Press the + to increase and - to decrease. Adjust to give the lumbar region of your pick the desired support.



Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit road conditions.

For further information contact ISRI Seats Ph:- (02) 9756 6199

www.isri.com.au