



## ISRI NCS 6830KM/870 Air Suspension Seat - Operator instructions

**SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED**

### **Three Point Seat Belt**

### **Air Suspension Adjustment**

Press the + to increase and - to decrease the air pressure in the seat suspension. The optimum setting being middle of the suspension stroke.

***This is not to be used as height control***

### **Seat Cushion Adjustment**

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

### **Seat Tilt Adjust**

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

### **Slide Adjust**

Lift slide handle and slide seat back/forward to the required position. Release to lock.

### **Heater**

Push toggle switch down to turn on and the up to turn off.

### **Armrest, Optional**

Turn the knob left to right to raise or right to left to lower the front of the armrest.

### **Backrest Adjustment**

Apply light pressure to backrest and gently lift lever and lean rearward/forward to adjust the backrest incline. Release lever to lock.

### **IPS Air Lumbar Support**

Press the (+) to increase and (-) to decrease. Adjust individual chambers to give the Lumbar region of your back the desired Support.

**Note-** When operating lumbar seat will exhaust then return to seated height.

### **Shock Absorber Adjustment**

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit conditions.

For further information contact  
**ISRI Seats**

Phone: (02) 9756 6199

Web: [www.isri.com.au](http://www.isri.com.au)





## ISRI NCS 6830KM/870 Air Suspension Seat - Operator instructions

**SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED**

### Three Point Seat Belt

### Air Suspension Adjustment

Press the + to increase and - to decrease the air pressure in the seat suspension. The optimum setting being middle of the suspension stroke.

**This is not to be used as height control!**

### Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

### Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

### Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.



### Armrest, Optional

Turn the knob left to right to raise or right to left to lower the front of the armrest.

### Backrest Adjustment

Apply light pressure to backrest and gently lift lever and lean rearward/forward to adjust the backrest incline. Release lever to lock.

### IPS Air Lumbar Support

Press the (+) to increase and (-) to decrease. Adjust individual chambers to give the Lumbar region of your back the desired Support.

**Note-** When operating lumbar seat will exhaust then return to seated height.

### Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit conditions.

### Heater

Push toggle switch down to turn on and the up to turn off.

For further information contact

ISRI Seats

Phone: (02) 9756 6199

Web: [www.isri.com.au](http://www.isri.com.au)



## ISRI NCS 6830KM/870 Air Suspension Seat - Operator instructions

**SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED**

### Three Point Seat Belt

### Air Suspension Adjustment

Press the + to increase and - to decrease the air pressure in the seat suspension. The optimum setting being middle of the suspension stroke.

**This is not to be used as height control!**

### Seat Cushion Adjustment

The seat cushion position can be adjusted, gently pull the lever up whilst sitting on the seat and push hips forward/backwards. Release to lock.

### Seat Tilt Adjust

Gently pull lever up and lean back on the backrest to tilt the seat up. Gently pull the lever up and lean forward to tilt the seat down. Release to lock.

### Slide Adjust

Lift slide handle and slide seat back/forward to the required position. Release to lock.



### Armrest, Optional

Turn the knob left to right to raise or right to left to lower the front of the armrest.

### Backrest Adjustment

Apply light pressure to backrest and gently lift lever and lean rearward/forward to adjust the backrest incline. Release lever to lock.

### IPS Air Lumbar Support

Press the (+) to increase and (-) to decrease. Adjust individual chambers to give the Lumbar region of your back the desired Support.

**Note-** When operating lumbar seat will exhaust then return to seated height.

### Shock Absorber Adjustment

Gently push the lever down for a firmer suspension, lift lever for a softer suspension. Adjust to suit conditions.

### Heater

Push toggle switch down to turn on and the up to turn off.

For further information contact

ISRI Seats

Phone: (02) 9756 6199

Web: [www.isri.com.au](http://www.isri.com.au)